Feature operation

Call Forward			
Activate	Fwd	⠿	▶ Fwd
Deactivate	▶ Fwd		
Reinstate	Fwd	▶ Fwd	

Call PickUp		
	☎	Pickup

Conference			
	Conf	⠿	▶ Conf

Hold	
Place a call on hold	(Hold)
Return to a held call	(Line)

Last Number Redial		
	☎	(Line)

Message		
	☎	(Msg/Inbox)

Ring Again		
Activate	RngAgn	
When notified	☎	▶ RngAgn
Deactivate	▶ RngAgn	

Transfer			
	Trans	⠿	▶ Trans

Adjust volume			
	🔊 (Volume +)	or	🔊 (Volume -)

Legend

Icon	Action
( )	Indicates the key cap text label. For example, (Message).
☎	Lift the handset.
↓	Replace the handset.
(Goodbye)	Press the goodbye key.
⠿	Dial a number.

Legend (continued)

Icon	Action
(Line	Press the line key.
▶ Fwd	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
(Services)	Press the **Services** key once for server-based features, or press the **Services** key twice for local phone features.
(Message/Inbox)	Press the **Message/Inbox** key.
(Up/Down) / (Enter)	Press the **Up/Down Navigation** keys. Press the **Enter** key
(Expand)	Press the **Expand** key

Services and Telephone Options menus

Services menu
(Services)   (Up/Down)   (Enter)

Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1110 phones. Consult your system administrator.

Telephone Options menu

The following are the most commonly used options:

Volume adjustment
Choose one of: . Ringer . Handset Listen . Listen-only speaker . Buzzer   (Enter)   (Up/Down)   (Enter)

Contrast adjustment
(Up/Down)   (Enter)

Language
(Up/Down)   (Enter)

Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.

Date/Time format
(Up/Down)   (Enter)

Local DialPad Tone
(Up/Down)   (Enter)

Ring type
(Up/Down)   Play   (Enter)

Call Timer
On   Off   (Enter)

Nortel IP Phone 1110

- Feature Status Lamp*
- Visual Alerter/Message Waiting indicator
- LCD display screen
- Context-sensitive soft keys
- Navigation keys
- Message/Inbox key
- Enter key
- Goodbye key
- Hold key
- Line key
- Expand key
- Handset
- Services key
- Speaker
- Volume keys
- Dialpad

*Note: If supported by your server, the Feature Status Lamp provides a user-defined alert. Contact your system administrator to find out if this feature is available for you.

NORTEL

IP Phone 1110

For Nortel Communication Server 1000

Quick Reference Card

To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.